



Anziehvorschrift für Zylinderkopf		150.801	 Das Original	
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a VW/AUDI		
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
 057.240 M12x166-10.9				
Anziehen/ Tightening/ Serrage/ Apriete		* ➤ ➤	30 Nm 60 Nm 90° 90°	
Zeichenerklärung / Explanations / Explication / Explicacion				
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage	emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
2,0 Ltr. TDI 91, 100, 103 kW (124,136,140 PS) ✚ 1,61mm 3 Löcher, Holes, Trous, Agujeros, Fori Mot. BMM, BGW, BHW, BMP, BVH, BRT, BPW, BRC, BSS BWW, CBKA, CBHA, CBJB				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*150.801*	