

Anziehvorschrift für Zylinderkopf		505.650 passend für / suitable for adaptable à / adaptable a PSA Peugeot/Citroën	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
⑥④②⑦ ⑧①③⑤				
Anziehen/ * 20 Nm Tightening/ 40 Nm Serrage/ 80 Nm Apriete ➤ 180°				
Zeichenerklärung / Explanations / Explication / Explicacion				
*	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Peugeot 607		ab 2004➔		
Peugeot 407		ab 2005➔		
Citroën C6		ab 2005➔		
Citroën C5		ab 2008➔		
Mot.: DT17TED4/UHZ 2,7 Ltr. HDi				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*505.650*	